



# 2N Access Unit M

## Installation Manual



# Table of Contents

<b>Symbols and Terms Used .....</b>	<b>3</b>
<b>Product Description .....</b>	<b>4</b>
Basic Features .....	4
Product Versions .....	5
Accessories .....	7
Accessories for Installation .....	7
Extenders .....	8
Power Supply .....	8
Other accessories .....	9
Package Completeness Check .....	13
Package Completeness Check for Installation Accessories .....	13
<b>Installation .....</b>	<b>15</b>
Mechanical Installation .....	15
Installation Conditions .....	15
Surface Installation .....	16
Surface installation on mounting backplate .....	17
Flush mounting .....	20
Electric Installation .....	24
Power Supply .....	24
Cabling Description .....	25
Cable Connection .....	27
LAN Connection .....	27
Overvoltage Protection .....	29
<b>Brief Guidelines .....</b>	<b>33</b>
Device Configuration Interface Access .....	33
Domain Name .....	33
IP address .....	33
Web Configuration Interface Login .....	33
Configuration via Hardware .....	34
Device Restart .....	34
Factory Default Reset .....	34
IP Address Retrieval .....	34
IP Address Retrieval Using <b>2N Network Scanner</b> .....	34
Firmware Update .....	36
Device Restart .....	36
Restart Using RESET Button .....	36
Restart Using Web Configuration Interface, .....	36
Factory Default Reset .....	36
Factory Default Reset .....	37
<b>Device Control .....</b>	<b>38</b>
Signaling of Operational Statuses .....	38
<b>Maintenance - Cleaning .....</b>	<b>39</b>
<b>Troubleshooting .....</b>	<b>40</b>
<b>Technical Parameters .....</b>	<b>41</b>
<b>General Instructions and Cautions .....</b>	<b>44</b>
Directives, Laws and Regulations .....	44
EU .....	44
Industry Canada .....	45
Legislation of Thailand .....	45
Electric Waste and Used Battery Pack Handling .....	45

## Symbols and Terms Used

The following symbols and pictograms are used in the manual:



### **DANGER**

**Always abide** by this information to prevent persons from injury.



### **WARNING**

**Always abide** by this information to prevent damage to the device.



### **CAUTION**

**Important information** for system functionality.



### **TIP**

**Useful information** for quick and efficient functionality.



### **NOTE**

Routines or advice for efficient use of the device.

# Product Description

In this section, we introduce the **2N Access Unit M** product, outline its application options and highlight the advantages following from its use.

## Basic Features

**2N Access Unit M** is an elegant and reliable IP system equipped with a number of useful functions. **2N Access Unit M** is designed as a robust, mechanically resistant access system, which withstands any weather conditions without requiring additional accessories.

**2N Access Unit M** is a single-module access system available in several versions. All the versions include an integrated card reader module, which helps control access using an RFID card. With additional software settings, functions other than the door lock switch can be RFID card controlled too.

The **2N Access Unit M** keypad version helps you control the electric lock switch by entering a valid numeric code via the numeric keypad. With additional software settings, functions other than the door lock can be RFID card controlled too.

The **2N Access Unit M** Bluetooth version helps you control the lock switch using the **2N My2N** application installed in your smartphone. **2N Access Unit M** is designed as a resistant IP55-rated access system, which withstands any weather conditions without requiring additional accessories.

The installation of **2N Access Unit M** is very easy. All you have to do is connect the system to your LAN via a mains cable. Feed the device from a 12 V power supply or your PoE supporting LAN.

Use a PC equipped with any internet browser to configure **2N Access Unit M**. extensive access system installations easily.

Advantages of Use **2N Access Unit M**:

- Elegant mullion design,
- Cover rating,
- Variable installation options (flush mounting into brick/plasterboard walls, surface installation, door frame mounting),
- Integrated electric lock switches with wide setting options,
- Integrated RFID card reader module,
- Bluetooth module version or backlit touch keypad,
- Configuration using web interface,
- HTTP server for API configuration,
- SNTP client for server time synchronization,
- SMTP client for e-mail sending,
- TFTP/HTTP client for automated configuration and firmware update,
- LAN (PoE) or external 12 V power supply.



## Product Versions



### Part No. 9161121

Axis Part No. 02909-001

#### **2N Access Unit M 13.56 MHz, NFC ready**

Combining an access reader and a controller, the device is used for access control inside and outside of buildings.

The device is used for reading RFID cards in the 13.56 MHz bandwidth with the NFC support.

It is a 3m LAN cable version.

Supported RFID cards 13.56 MHz:

- **ISO14443A** (MIFARE Classic, MIFARE Plus, MIFARE Mini, MIFARE Ultralight, MIFARE DESFire CSN only)
- **PicoPass** (HID iClass CSN, Picopass)
- **FeliCa** (Standard, Lite)
- **ST SR** (SR, SRI, SRIX)
- **My2N**
- **2N PICard**



### Part No. 9161141

Axis Part No. 02910-001

#### **2N Access Unit M RFID – 125 kHz, 13.56 MHz, NFC**

Combining an access reader and a controller, the device is used for access control inside and outside of buildings.

The device is used for reading RFID cards in the 125 kHz and 13.56 MHz bandwidths with the NFC support.

It is a 3m LAN cable version.

Supported RFID cards 125 kHz:

- EM4x02
- NXP HiTag2

Supported RFID cards 13.56 MHz:

- **ISO14443A** (MIFARE Classic, MIFARE Plus, MIFARE Mini, MIFARE Ultralight, MIFARE DESFire CSN only)
- **PicoPass** (HID iClass CSN, Picopass)
- **FeliCa** (Standard, Lite)
- **ST SR** (SR, SRI, SRIX)
- **My2N**
- **2N PICard**



**Part No. 9161151**

Axis Part No. 02911-001

**2N Access Unit M Bluetooth & RFID – 125 kHz, 13.56 MHz, NFC**

Combining an access reader, a touch keypad and a controller, the device is used for access control inside and outside of buildings.

The device is used for reading RFID cards in the 125 kHz and 13.56 MHz bandwidths with the NFC support.

It is a 3m LAN cable version.

Supported RFID cards 125 kHz:

- EM4x02
- NXP HiTag2

Supported RFID cards 13.56 MHz:

- **ISO14443A** (MIFARE Classic, MIFARE Plus, MIFARE Mini, MIFARE Ultralight, MIFARE DESFire CSN only)
  - **PicoPass** (HID iClass CSN, Picopass)
  - **FeliCa** (Standard, Lite)
  - **ST SR** (SR, SRI, SRIX)
  - **My2N**
  - **2N PICard**
-



**Part No. 9161161**

Axis Part No. 02912-001

**2N Access Unit M Touch keypad & RFID – 125 kHz, 13.56 MHz, NFC**

Combining an access reader, a touch keypad and a controller, the device is used for access control inside and outside of buildings.

The device is used for reading RFID cards in the 125 kHz and 13.56 MHz bandwidths with the NFC support.

It is a 3m LAN cable version.

Supported RFID cards 125 kHz:

- EM4x02
- NXP HiTag2

Supported RFID cards 13.56 MHz:

- **ISO14443A** (MIFARE Classic, MIFARE Plus, MIFARE Mini, MIFARE Ultralight, MIFARE DESFire CSN only)
- **PicoPass** (HID iClass CSN, Picopass)
- **FeliCa** (Standard, Lite)
- **ST SR** (SR, SRI, SRIX)
- **My2N**
- **2N PICard**

## Accessories

### Accessories for Installation

**2N Access Unit M** is designed for door frame mounting both outdoors and indoors.

Choose the proper accessories for your particular installation needs.



**Part No. 916121**

Axis Part No. 02940-001

**Flush mounting box**

The flush mounting box is used for connection and storage of cables below the device.



**Part No. 916122**

Axis Part No. 02932-001

**Mounting backplate**

The wall mounting backplate is used for connection and storage of cables below the device.

## Extenders

### Part No. 9159010

Axis Part No. 01386-001



#### Security Relay

A handy add-on that significantly enhances security. It prevents lock tampering.

To be installed between the protected device from which it is also powered and the lock controlled by it.

---

### Part No. 9155198SET

Axis Part No. 01975-001



#### Security Package for 2N Devices

The security package provides increased door security.

The safety package includes a safety relay, a protection switch and an I/O module.

---

## Power Supply

### Part No. 91378100E (with EU cable)

### Part No. 91378100US (with US cable)

Axis Part No. 01403-001



One-port PoE injector

For intercom supply via Ethernet cable where the PoE switch is absent.

---

### Part No. 91341481E (with EU cable)

### Part No. 91341481US (with US cable)

Axis Part No. 02520-001



#### Stabilized 12 V / 2 A power supply

The supply must be used where PoE is not used.

---



**Part No. 932928**

Axis Part No. 02529-001

**12 V transformer**

For 230 V mains voltage.

Designed for external supply of electric locks.

## Other accessories



**Part No. 9159013**

Axis Part No. 02523-001

**Departure button**

The departure button is connected to the device logic input for opening the door from inside the building.



**Part No. 9159012**

Axis Part No. 01388-001

**Magnetic door contact**

Set for installation on a door, enabling the status of door opening to be ascertained. Used where the device is used for door protection, open door detection or forced opening.



**Part No. 9134173**

Axis Part No. 01384-001

**MIFARE RFID chip card, 13.56 Hz**

RFID chip card, MIFARE Classic 1k, 13.56 MHz.



**Part No. 9134174**

Axis Part No. 01385-001

**MIFARE RFID chip fob, 13.56 MHz**

RFID chip fob, MIFARE Classic 1k, 13.56 MHz.

**Part No. 9134165E**

Axis Part No. 01395-001



**EM RFID chip card, 125 Hz**

RFID chip card, type EM4100, 125 kHz.

---

**Part No. 9134166E**

Axis Part No. 01396-001



**EM RFID chip fob, 125 kHz**

RFID chip fob, type EM4100, 125 kHz.

---

**Part No. 11202601**

Axis Part No. 02787-001



**MIFARE DESFire RFID chip card, 13.56 MHz**

RFID chip fob, type MIFARE DESFire EV3 4 K, 13.56 MHz (ISO/IEC14443A).

Suitable for data encryption in **PICard Commander**.

The package includes 10 pieces.

---

**Part No. 11202602**

Axis Part No. 02788-001



**MIFARE DESFire RFID fob, 13.56 MHz**

RFID fob, type MIFARE DESFire EV3 4 K, 13.56 MHz (ISO/IEC14443A).

Suitable for data encryption in **PICard Commander**.

The package includes 10 pieces.

---

**Part No. 9137420E**

Axis Part No. 01399-001



**External RFID reader, 125 kHz**

External RFID card reader connectable to a PC via a USB interface.

Suitable for system administration and adding of EM41xx cards (125 kHz) using the device web configuration or **PICard Commander**.



**Part No. 9137421E**

Axis Part No. 01399-001

**External RFID reader, 13.56 MHz + 125 kHz, NFC/HCE**

External RFID card reader connectable to a PC via a USB interface.

Suitable for system administration and adding of 13.56 MHz/125 kHz cards and Android devices with NFC/HCE support using the device web configuration or the **Access Commander**.

Suitable for uploading of MIFARE DESFire cards into the **PICard Commander** encryption application.

The following RFID cards can be read:

Supported RFID cards 125 kHz:

- EM4x02
- NXP HiTag2

Supported RFID cards 13.56 MHz:

- **ISO14443A** (MIFARE Classic, MIFARE Plus, MIFARE Mini, MIFARE Ultralight, MIFARE DESFire CSN only)
- **PicoPass** (HID iClass CSN, Picopass)
- **FeliCa** (Standard, Lite)
- **ST SR** (SR, SRI, SRIX)
- **My2N**
- **2N PICard**

The device can also read the 13.56 MHz 2N PICard RFID cards.

---

**Part No. 9137424E**



Axis Part No. 01527-001

**External secured RFID reader, 13.56 MHz + 125 kHz, NFC/HCE**

External secured RFID card reader connectable to a PC via a USB interface.

Suitable for system administration and adding of 13.56 MHz/125 kHz cards and Android devices with NFC/HCE support using the device web configuration or the **Access Commander**.

Suitable for uploading of MIFARE DESFire cards into the **PICard Commander** encryption application.

The following RFID cards can be read:

Supported RFID cards 125 kHz:

- EM4x02
- NXP HiTag2
- HID Prox

Supported RFID cards 13.56 MHz:

- **ISO14443A** (MIFARE Classic, MIFARE Plus, MIFARE Mini, MIFARE Ultralight, MIFARE DESFire CSN only)
- **PicoPass** (HID iClass CSN, Picopass)
- **FeliCa** (Standard, Lite)
- **ST SR** (SR, SRI, SRIX)
- **My2N**
- **2N PICard**

---

**Part No. 9137410E**



Axis Part No. 01397-001

**External IP relay, 1 output**

Stand-alone IP relay, which can be controlled from an intercom via HTTP commands and helps control devices from an unlimited distance.

---

**Part No. 9137411E**



Axis Part No. 01398-001

**External IP relay, 4 outputs, PoE**

Stand-alone IP relay, which can be controlled from an intercom via HTTP commands and helps control devices from an unlimited distance.

---



**Part No. 9159014EU/US/UK**

Axis Part No. 01404-001




**2N 2Wire** (set of 2 adaptors and power source for EU/US/UK)

The 2N 2Wire converter allows you to use the existing 2-wire cabling from your original doorbell or door intercom for connecting any IP device. You do not have to configure anything, all you need is one 2N 2Wire unit at each end of the cable and a power supply connected to at least one of these units. The 2N 2Wire unit then provides PoE power not only to the second converter, but to all of the connected IP end devices.

---

**Part No. 9160501**

Axis Part No. 0820-001



**AXIS A9188 Network I/O Relay Module**

The relay is part of the lift access solution. One relay can control up to 8 floors. Intercom or access unit can be interconnected with up to 8 AXIS A9188 lift relays. The solution is thus suitable for up to 64 floors.

## Package Completeness Check

Please check the product delivery before installation. Contents:

1x **2N Access Unit M**

---

1x Certificate of ownership

---

1x Quick Start manual

---

1x Metal wall holder (screwed to the device)

---

2x 8 x 40 mm dowel

---

2x 4.5 x 40 mm flat head screw with washer

---

1x M 3 x 8 mm stainless steel lens head screw for fitting device in holder (ISO 14583)

---

1x T10 and T20 dual Torx key

## Package Completeness Check for Installation Accessories

The flush mounting box package for **2N Access Unit M** includes:

## Product Description

### Part No. 916121

2x 3.5 x 8 mm thread-forming lens head screw for plastic with integrated backplate (WN 1411)

1x 3 x 16 mm thread-forming lens head screw for plastic (WN 1412)

The backplate package for **2N Access Unit M** includes:

### Part No. 916122

2x 3.5 x 8 mm thread-forming lens head screw for plastic with integrated backplate (WN 1411)

# Installation

## Mechanical Installation

### Installation Conditions

**Make sure that the following 2N Access Unit M installation conditions are met.**

- There must be enough space for the device installation.
- Make sure that the dowel holes have the required diameter. If the diameters are too large, the dowels may get loose! Use the mounting glue to secure the dowels if necessary.
- Do not use low-quality dowels to avoid their falling out of the wall!
- Make sure that the depths of the dowel holes are accurate!
- Before starting the mechanical installation on a selected place, make sure carefully that the preparations associated with it (drilling, wall cutting) cannot damage the electrical, gas, water and other existing wires and pipes.
- The device is designed for vertical wall mounting (perpendicular to the floor) in the height of up to 1350 mm above the floor. If necessary, operate the device in a position other than as aforementioned for a short time only, for quick testing purposes in a servicing center, for example.
- Make sure that the plasterboard interior does not show a pressure value significantly different from that of the room, e.g. that it is not connected with overpressure ventilation. If the difference is too great, separate the device in terms of pressure (using, e.g., a mounting box) and seal the cable passage.
- The device is not designed for environments with increased vibrations such as means of transport, machine rooms and so on.
- The device is not intended for dusty environments and places with unstable humidity and abrupt temperature changes.
- The device may not be exposed to aggressive gas, acid vapors, solvents, etc.
- The device is not intended for direct connection into the Internet/WAN. The device must be connected to the Internet/WAN via a separating active network element (switch/router).
- The device cannot be operated on places exposed to direct sunshine and near heat sources.
- Keep some free space above and below the device to allow air to flow and conduct heat away.
- Avoid strong electromagnetic radiation on the installation site.
- Make sure that the VoIP connection is configured properly according to the SIP and other VoIP recommendations.




### CAUTION

- When the proper installation instructions are not met, water might get in and destroy the electronics. As the device circuits are constantly under voltage water leakage causes electrochemical reaction. The manufacturer's warranty shall be void for products damaged in this way!
- Exceeding the allowed operating temperature may not affect the device immediately but leads to premature ageing and lower reliability. For the acceptable range of operating temperatures and relative humidity values refer to [S. Technical Parameters](#).
- Any intentional mechanical damage to the device (drilling, main unit tampering, etc.) results in a loss of warranty.
- The device installation and setting should only be performed by professionally qualified persons.

## Surface Installation

**2N Access Unit M** is designed for surface mounting in its basic package without accessories (wall, plaster-board, door frames).



What you need for mounting:


- **2N Access Unit M**
- Metal wall holder (screwed to the device)




### TIP

Download the [drilling template](#) from 2N.com.


1.




2.



3.



4.



1. Use the drilling template shown on the device box to prepare holes of the required sizes for cabling and dowels on the selected place in the required height. Feed the cables out of the pre-drilled hole.
2. Pull the metal holder downwards to remove it from the device back side.



## WARNING

Do not handle the screws on the device back side!

3. Then fit the holder through the dedicated holes using the screws enclosed.
4. Interconnect the accessible cables with the cabling **2N Access Unit M**. Put the device carefully on the installed holder from above downwards and fix its position on the holder carrying elements by tightening the screw from the bottom through the holder hole.


## Surface installation on mounting backplate

The mounting backplate is used for placing cables below the device **2N Access Unit M** during surface installation.



## NOTE

Shortening the LAN cable in units Part No. **9161121**, **9161141**, **9161151** and **9161161** shall not render the warranty null and void.



---

What you need for mounting:


- **2N Access Unit M**
- Mounting backplate (Part No. **916122**)
- Metal wall holder (screwed to the device)




**TIP**

Download the [drilling template](#) from 2N.com.


1.




2.




3.




4.



5.



6.



## WARNING

Do not handle the screws on the device back side!

1. Prepare dowel holes on a selected place and in a selected height using a drilling template shown on the package. Cut a cable installation hole in the backplate.

2. Pull the metal holder downwards on the device back side to remove it.
3. Put the cables in the backplate and put the backplate against the wall. If you connect the device to installed cables, connect the wires.



### WARNING

Insulate the wire joints with a shrink tube and glue to keep the cover rating as much as possible.

4. Anchor the backplate to the base using screws and dowels. Screw the metal holder to the backplate.
5. Put the device on the backplate and insert the remaining cables carefully in the backplate.
6. Insert the device on the holder by pulling it from top to bottom making sure that the holder stops drive under the screw heads on the device back side. When the device touches the holder carrying elements, fix the device position by tightening the screw through the holder hole from the bottom.

## Flush mounting


The flush mounting box allows you to place cables in the wall below **2N Access Unit M** and mount the device.



### NOTE

Shortening the LAN cable in units Part No. **9161121**, **9161141**, **9161151** and **9161161** shall not render the warranty null and void.











What you need for mounting:

- **2N Access Unit M**
- Flush mounting box (Part No. **916121**)
- Metal wall holder (screwed to the device)




**TIP**


Download the [drilling template](#) from 2N.com.




7.




8.




9.



10.



11.



**WARNING**

Do not handle the screws on the device back side!

1. Make a hole of the size of 1300 (h) x 400 (w) x 650 (d) mm for the mounting box installation. Remove the box cover and the cable installation blank.
2. Replace the cover on the box to be used as a walling spacer. If the box location is convenient, wall the box in.
3. When the walling material has hardened, break off the side stops.



### WARNING

Insulate the wire joints with a shrink tube and glue to keep the cover rating as much as possible!

4. Remove the cover from the box.
5. Pull the metal holder downwards on the device back side to remove it.
6. Fit the holder to the box cover using the included screws.
7. Pull the cables leading from the device through the cover hole. Press the holder screwed to the cover to the device and move it upwards carefully to make the holder stops drive under the screw heads on the device back side.
8. If you connect the device to accessible cables, hang the device on the cover with the cover hooks into the box bottom holes. Connect the wires.
9. Insert the wires in the box keeping in mind that the maximum cable length is 250 mm.
10. Insert the cover with the device in the box. Pull the device carefully upwards to release it from the holder. Turn the device bottom part by approx. 30° to the left along the wall without moving it away from the wall. Tighten the screw into the hole on the right-hand bottom part of the box to anchor the box cover.
11. Replace the device into the vertical position and put on the holder. When the device touches the holder carrying elements, fix the device position by tightening the screw through the holder hole from the bottom. Push the device upper part to fix the device in the final position.

## Electric Installation

### Power Supply

**2N Access Unit M** can be fed either directly from the LAN if equipped with PoE 802.3af (Class 0, max. 12,95 W) supporting network elements or from an external 12 V  $\pm$  1 V / 1 A DC power supply.



### CAUTION

- Make sure that the external power supply meets the power supply class 2 (PS2/LPS) .



### WARNING

**2N Access Unit M** cannot be fed from an external power supply and PoE at the same time. A combined supply might result in a device damage.

### PoE Supply

**2N Access Unit M** is compatible with the PoE 802.3af (Class 0, max. 12,95 W) technology (Class 0, max. 12,95 W) and can be supplied directly from the LAN via compatible network elements. If your LAN does not support this technology, insert a PoE injector, between **2N Access Unit M** and the nearest network element. This power supply provides **2N Access Unit M** with 12 W for its own feeding .

## External Power Supply

Use a 12 V  $\pm$  1 V SELV supply dimensioned to the current consumption according to the required power output for to make your device work reliably.



### CAUTION


Make sure that the wires are firmly attached to the terminal to avoid any free contact.

## Adapter Connection (1341481, 02520-001)

The white wire at the end of the adapter carries the positive charge (+), the black wire carries the negative charge (-).


## Cabling Description

### Cable connection for Part Nos. 9161121, 9161141, 9161151, 9161161



The LAN cable is 3 m long and RJ-45 male terminated. All the other available cables are 35 cm long.

### Cable connection for Part Nos. 9161112, 9161114, 9161115, 9161116



The LAN cable is RJ-45 female terminated. All the available cables are 35 cm long.

Legend to figure	Component	Description
1	RELAY	Relay cable with a 30 V / 1 A AC/DC NO/NC contact. Used for connection of non-critical devices only (lights, e.g.).
2/3	Input 1/2	<p>The terminals are used as inputs in the passive/active mode (<math>-30</math> V to <math>+30</math> V DC) for departure button, open door sensor, ESS etc. connection</p> <ul style="list-style-type: none"> <li>• OFF = open contact OR <math>U_{IN} &gt; 1.5</math> V</li> <li>• ON = closed contact OR <math>U_{IN} &lt; 1.5</math> V</li> </ul>

Legend to figure	Component	Description
4	Ext. Power	For external power supply connection (12 V / 1 A).
5	Active output	An active output cable for the connection of <b>the Security Relay</b> or an electric lock: 8 to 12 V DC according to power supply (PoE: 10 V; adapter: power supply voltage minus 2 V), up to 600 mA.
6	LAN cable	For LAN connection (PoE 802.3af (Class 0, max. 12.95 W)).
7	Tamper Switch	A switch that helps detect the removal of a device from the holder installed.
8	RESET	RESET / FACTORY RESET button.

The table below includes the device cabling color marking. The colors are different for different device models:

Part No.	1	2	3	4	5
<b>9161121,</b> <b>9161141,</b> <b>9161151,</b> <b>9161161</b>	yellow NO, brown NC, gray COM	pink "+", blue "-"	orange "+", green "-"	red "+", black "-"	white "+", violet "-"
<b>916112,</b> <b>916114,</b> <b>916115, 916116</b>	yellow NO, red NC, black COM	red "+", black "-"			




#### WARNING

The 12V output is used for lock connection. If the device is installed in a location where there is a danger of unauthorized access (building front, e.g.), we strongly recommend the use of the 2N Security Relay (9159010, 01386-001) to ensure the maximum installation security.

**WARNING**

If a coil containing device is connected, e.g. relays/electromagnetic locks, it is necessary to protect the device output against voltage peak while switching off the induction load. For this way of protection we recommend a 1 A / 1000 V diode (e.g., 1N4007, 1N5407, 1N5408) connected antiparallel to the device.



1. Terminals
2. Coil. e.g. relay or electromagnetic lock

**Cable Connection**

The **2N Access Unit M** signals are led out by insulated wires stripped 1 cm at the ends (this does not apply to the Ethernet cable with a connector). Choose any of the below mentioned methods to connect the wires:

- by twisted pair,
- using a terminal board,
- by soldering,
- screw connection,
- using WAGO terminals,
- crimping using sockets.

**LAN Connection**

**2N Access Unit M** is connected to the LAN by inserting a SSTP cable (category Cat-5e or higher) in the dedicated LAN connector on the device. As the device is equipped with the Auto-MDIX function, you can use either the straight or crossed cable version.

This device must be deployed within a network infrastructure that provides adequate protection against Denial-of-Service (DoS) attacks and similar network-based threats. The device does not include built-in protection against high-volume or malicious traffic and relies on the surrounding network environment—such as firewalls, intrusion prevention systems, or rate limiting—for defense. Failure to implement appropriate network security measures may lead to service degradation or unavailability. The equipment's user documentation shall contain a [description of all exposed network interfaces and all services exposed via network interfaces](#), which are delivered as part of the factory default state.

**CAUTION**

- We recommend the use of a LAN [surge protection](#) (p. 29).
- We recommend the use of a shielded SSTP Ethernet cable.

**Power Consumption for Device Versions**

State	Part Nos. 916112/9161121  Axis Part No. 02393-001/02909-001	Part Nos. 916114/9161141  Axis Part No. 02394-001/02910-001	Part Nos. 916115/9161151  Axis Part No. 02395-001/02911-001	Part Nos. 916116/9161161  Axis Part No. 02396-001/02912-001
At re- lax	1.6 W	1.5 W	1.5 W	1.5 W
LED – white strip 100 %	0.12 W	0.12 W	0.12 W	0.12 W
LED – green strip 100 %	0.15 W	0.15 W	0.15 W	0.15 W
LED – red strip 100 %	0.20 W	0.20 W	0.20 W	0.20 W
LED – Blue- tooth 100 %	–	–	0.06 W	–
LED – key- pad back- light 100 %	–	–	–	0.15 W



State	Part Nos. 916112/9161121	Part Nos. 916114/9161141	Part Nos. 916115/9161151	Part Nos. 916116/9161161
	Axis Part No. 02393-001/02909-001	Axis Part No. 02394-001/02910-001	Axis Part No. 02395-001/02911-001	Axis Part No. 02396-001/02912-001
Relay at stand- ard room tem- pera- ture mode	0.14 W	0.14 W	0.14 W	0.14 W
OUT1 at maxi- mum possi- ble load	6 W	6 W	6 W	6 W
Audio	0.7 W	0.7 W	0.7 W	0.7 W

## Overvoltage Protection


The 2N device cables have to be protected against atmospheric overvoltage caused by external causes (lightning, e.g.). A surge can damage a device installed outside/inside the building if the wires are unprotected.

Therefore, we recommend that additional overvoltage protectors (OVP) be installed on the outer walls or roof for all the wires leading outside the building. Keep the following instructions while installing overvoltage protectors:


- Make sure that the overvoltage protector is installed as close as possible to the device installed outside the building.
- Make sure that the overvoltage protector is installed as close as possible to the device installed on an external part of the building.
- Make sure that the overvoltage protector is installed as close as possible to the point where the cabling leaves the building.

## Examples of Overvoltage Protection Installation


Overvoltage protection installation diagram for a device installed on the building facade and cables outside the building



**Overvoltage protection installation diagram for a device installed on the building facade and cables inside the building**



# **Overvoltage protection installation diagram for a device and cables installed outside the building**



# Brief Guidelines

- [Device Configuration Interface Access \(p. 33\)](#)
- [Configuration via Hardware \(p. 34\)](#)
- [IP Address Retrieval \(p. 34\)](#)
- [Firmware Update \(p. 36\)](#)
- [Device Restart \(p. 36\)](#)
- [Factory Default Reset \(p. 36\)](#)

## Device Configuration Interface Access

**2N Access Unit M** is configured via the web configuration interface. You have to know the device IP address or the device domain name. Make sure that the device is connected to the local IP network and powered.

### Domain Name

Enter the device domain name as “hostname.local” to connect to the device. The hostname of a new device consists of the device name and serial number. Enter the serial number into the domain name without dashes. Change the hostname anytime in **System > Network**.

**Default domain name 2N Access Unit M:** 2NAccessUnitM-{serial number without dashes}.local (e.g.: “2NAccessUnitM-0000000001.local”)

Login based on a domain name is advantageous if the dynamic IP address is used. While the dynamic IP address changes, the domain name remains the same. It is possible to generate certificates signed by a trusted certification authority for the domain name.

### IP address

To retrieve the device IP address, take the following steps, see :

- Use the freely accessible **2N Network Scanner**.
- Use hardware (RESET button).

## Web Configuration Interface Login

1. Fill in the **2N Access Unit M** address or domain name into the internet browser.

The login screen is now displayed.

If the login screen is not displayed, check the IP address, port or domain name for validity. The login screen is not displayed if the web interface server is off. If no certificate has been generated for the IP address or domain name, a security certificate invalidity notification may appear. In that case, confirm that you want to go to the web configuration interface.

2. Enter the login data.

The default login data are:

Username: **Admin**

Password: **2n**

It is necessary to change the password immediately upon the first login.

After login using the default password, the access to the web configuration interface functions is limited.

**TIP**

It is recommended that a password is used that is difficult to break. It is not recommended that names, places or things, especially those closely related to the user, are used in the password.

For increased password security, it is recommended that:

- the random password generator is used,
- the password length is 12 characters at least,
- various characters from different character sets are combined (small/capital letters, digits, special characters, etc.).

## Configuration via Hardware

Where software configuration is unavailable, the basic settings can be made using the RESET button (for location see Subs. ).


The RESET button helps you reset the factory default values, restart the device, retrieve the device IP address and switch the IP address static/dynamic mode.

### Device Restart

Press the button shortly (< 1 s) to restart the system without changing configuration.

### Factory Default Reset

1. Press the button RESET and keep it pressed.
  - a. Wait until the red and green LEDs go on simultaneously on the device and the acoustic signal can be heard 🎵 (approx. 15–35 s).
  - b. Wait until the red LED goes off and the acoustic signal can be heard 🎵 (approx. for another 3 s).
  - c. Wait until the green LED goes off and the red LED goes on again and the acoustic signal can be heard 🎵 (approx. for another 3 s).
  - d. Wait until the red LED goes off and the acoustic signal can be heard 🎵 (approx. for another 3 s).
2. Release the RESET button.



## IP Address Retrieval


To retrieve the device IP address, take the following steps:

- Use the freely accessible **2N Network Scanner**.
- Use hardware (RESET button).

### IP Address Retrieval Using 2N Network Scanner

The application helps you find the IP addresses of all the 2N devices in the LAN. Download **2N Network Scanner** from the [2N.com](https://www.2n.com) website. Make sure that Microsoft .NET Framework 2.0 is installed for successful app installation.

1. Run the **2N Network Scanner** installer.
2. The Installation Wizard will help you with the installation.
3. Having installed **2N Network Scanner**, start the application using the Microsoft Windows Start menu. Once started, the application begins to automatically search the LAN for all the 2N devices which have been DHCP/statically assigned IP addresses. These devices are then shown in a table.



IP Address	Serial Number	Display Name	Version
10.0.24.69	54-1921-5022	2N IP Verso Mobile Team	2.29.0.38.6
10.0.24.73	52-1953-0073	2N Indoor Touch 2.0	4.0.0
10.0.24.74	54-0956-0004	2N Indoor Touch	3.4.0.1.0
10.0.24.75	52-1953-0064	2N Indoor Touch 2.0	999.4.3.0 (eng.378...
10.0.24.78	52-1953-0079	2N Indoor Touch 2.0	999.4.4.0 (eng.502...
10.0.24.79	52-2339-0077	2N Indoor Compact	2.30.0.39.0
10.0.24.87	52-2101-0046	2N Indoor Touch 2.0	4.3.0 (rc.4.3.x)
10.0.24.102	52-1953-0098	2N Indoor Touch 2.0	999.4.4.0 (eng.496...
10.0.24.105	52-2656-0067	2N Indoor View	2.29.0.38.6
10.0.24.108	52-2700-0559	2N Indoor Touch 2.0	999.4.4.0 (eng.494...
10.0.24.116	52-2667-0295	2N Indoor Touch 2.0	4.2.2 (release.4.2.2)
10.0.24.123	99-8888-0035	2N Indoor Touch 2.0	999.4.1.7 (eng.root...

Count: 15

4. Select the device to be configured and right-click it. Select *Browse...* to open the device administration web interface login box for configuration.



#### CAUTION

If the found device is grey highlighted, its IP address cannot be configured using this application. In that case, click *Refresh* to find the device again and check whether multicast is enabled in your network.



#### TIP

- Double click the selected row in the **2N Network Scanner** list to access the device web interface easily.
- To change the device IP address, select *Config* and enter the required static IP address or activate DHCP.

The default login data are:

Username: **Admin**

Password: **2n**

It is necessary to change the password immediately upon the first login.



**TIP**

It is recommended that a password is used that is difficult to break. It is not recommended that names, places or things, especially those closely related to the user, are used in the password.

For increased password security, it is recommended that:

- the random password generator is used,
- the password length is 12 characters at least,
- various characters from different character sets are combined (small/capital letters, digits, special characters, etc.).

## Firmware Update

We recommend that the firmware is also updated during the **2N Access Unit M** installation. Refer to [2N.com](https://2n.com) for the latest FW version.

Update firmware via the web configuration interface in System > Maintenance, refer to the device Configuration Manual.

Once the firmware is uploaded successfully, the device is restarted automatically.



**TIP**

You can make bulk updates for multiple devices via **2N Access Commander**.

## Device Restart

To restart the device choose one of the following options:

- using the RESET button,
- via the web configuration interface.



**NOTE**

The device restart does not result in any change in the configuration settings.

### Restart Using RESET Button

Press the button shortly (< 1 s) to restart the system without changing configuration.

### Restart Using Web Configuration Interface,

You can restart the device via the web configuration interface. Refer to [Web Configuration Interface Login \(p. 33\)](#) for login details. Restart the device in System > > System using **Restart**.

## Factory Default Reset


Reset the device factory default values via software in System > [Maintenance](#) Default reset.



Follow the instructions below **2N Access Unit M** to reset the factory default values via hardware:

## Factory Default Reset

1. Press the button RESET and keep it pressed.
  - a. Wait until the red and green LEDs go on simultaneously on the device and the acoustic signal can be heard 🗣️ (approx. 15–35 s).
  - b. Wait until the red LED goes off and the acoustic signal can be heard 🗣️ (approx. for another 3 s).
  - c. Wait until the green LED goes off and the red LED goes on again and the acoustic signal can be heard 🗣️ (approx. for another 3 s).
  - d. Wait until the red LED goes off and the acoustic signal can be heard 🗣️ (approx. for another 3 s).
2. Release the RESET button.



### CAUTION

In case the factory default values are reset on the device with a firmware version 2.18 or higher, it is necessary to reprogram the 2N Security Relay using the instructions given in [Security Relay](#).

## Device Control




**2N Access Unit M** is a single-module access system available in several versions. All the versions include an integrated card reader module, which helps control access using an RFID card. With additional software settings, functions other than the door lock switch can be RFID card controlled too.

The device control depends on the product version:

- using RFID cards and chips – by tapping a card/chip on the device,
- using the **2N My2N** application – by pressing the device touchscreen in the vicinity of a mobile device with **2N My2N** logged in,
- using NFC,
- by entering a numeric access code via a keypad application

### Signaling of Operational Statuses

The operational statuses **2N Access Unit M** are indicated by a light on the device front side. The light signal can be accompanied with an acoustic signal if set so. Refer to [5.3.3 Audio](#) of the 2N Access Unit Configuration Manual for the setting options.

Operational Status Visual Indication	Operational Status Description
	The white LED light indicates the power supply and operation states.
	<p>The green LED light goes on whenever a valid PIN code is entered via the keypad or a valid RFID card is applied. Subsequently, the set switch is activated.</p> <p>A valid authentication is indicated by an acoustic signal if set so.</p>
	<p>The red LED light goes on whenever an invalid PIN code is entered via the keypad or an invalid RFID card is applied. Subsequently, the set switch is not activated.</p> <p>An invalid authentication is indicated by an acoustic signal if set so.</p>



#### TIP

Set the LED backlight level in **Hardware > Backlight** in the web configuration. Refer to Subs. [5.3.4 Backlight](#) of the Configuration Manual for details.

## Maintenance - Cleaning

**2N Access Unit M** contains no environmentally harmful components. Dispose of the device in accordance with the applicable legal regulations.

If used frequently, the device surface gets dirty. Use a piece of soft cloth moistened with clean water to clean the device. Use appropriate cleaning agents suitable for glasses, optical devices, screens, etc. We recommend that IT cleaning wipes are used.

**CAUTION**

Use the product for the purposes it was designed and manufactured for, in compliance herewith. The manufacturer reserves the right to modify the product in order to improve its qualities.

If used frequently, the device surface gets dirty. Use a piece of soft cloth moistened with clean water to clean the device. Use appropriate cleaning agents suitable for glasses, optical devices, screens, etc. We recommend that IT cleaning wipes are used.

- Alcohol-based cleaners may not be applied.
- Clean the device in dry weather in order to make waste water evaporate quickly.
- Do not use aggressive detergents (such as abrasives or strong disinfectants).
- Prevent water from getting inside the device.

**TIP**

To disinfect the surface of the device against bacteria and viruses (Anti-Covid) and maintain the hygienic conditions of critical surfaces and touch points, we recommend that you use the Zoono – Microbe Shield Surface Sanitiser spray.

# Troubleshooting

Refer to <https://www.2n.com/faqs> for the most frequently solved problems.

# Technical Parameters

## Power Supply Types

PoE	IEEE PoE 802.3af (Class 0, max. 12,95 W) (Class 0, max. 12.95 W)
-----	--

External supply	12 V $\pm$ 1 V / 1 A DC
-----------------	-------------------------



### WARNING

**2N Access Unit M** cannot be fed from an external power supply and PoE at the same time. A combined supply might result in a device damage.

## Audio

Speaker	1 W / 8 $\Omega$
---------	------------------

Audio power output	
--------------------	--

## Interface

LAN	10/100BASE-TX with Auto-MDIX, RJ-45 female (pigtail)
-----	--

Recommended cabling	Cat-5e or higher
---------------------	------------------

Supported protocols	DHCP opt. 66, SMTP, 802.1x, TFTP, HTTP, HTTPS, Syslog
---------------------	---

Passive switch (relay)	NO/NC contact, up to 30 V / 1 A AC/DC
------------------------	---------------------------------------

Active switch output	9.8 to 13.8 V DC according to power supply, up to 600 mA
----------------------	--

- PoE: 11.6 V
- adapter: source voltage  $-0.4$  V

**Tamper Switch**  
(part of the 2N Access Unit M main unit)

Inputs	Can be used in passive or active mode (-30 V to +30 V DC)
	<ul style="list-style-type: none"> <li>• OFF = open or <math>U_{IN} &gt; 1.5 \text{ V}</math></li> <li>• ON = short-circuited or <math>U_{IN} &lt; 1.5 \text{ V}</math></li> </ul>

**Bluetooth**

Bluetooth	in compliance with BLE (Bluetooth Low Energy)
RX sensitivity	up to -98.9 dBm per 1 Mbps
Support of mobile applications	Android 6.0 Marshmallow and higher, iOS 12.0 and higher

**Mechanical Parameters**

Cover	Robust ASA/PC construction material, which is also used for such car parts as lateral mirrors, radiator masks, etc. + chemically hardened 3 mm thick glass
Weight	460 g
Operating temperature	-40 °C to 60 °C
Relative humidity	10 to 95 % (non-condensing)
Storing temperature	-40 °C to 70 °C
Recommended altitude	up to 2000 m
Protection class	IP55

**Mechanical Parameters**

Resistance level

IK07

## General Instructions and Cautions

Please read this User Manual carefully before using the product and follow the instructions and recommendations included therein.

Any use of the product that is in contradiction with the instructions provided herein may result in malfunction, damage or destruction of the product.

The manufacturer shall not be liable and responsible for any damage incurred as a result of a use of the product other than that included herein, namely undue application and disobedience of the recommendations and warnings.

Any use or connection of the product other than those included herein shall be considered undue and the manufacturer shall not be liable for any consequences arisen as a result of such misconduct.

Moreover, the manufacturer shall not be liable for any damage or destruction of the product incurred as a result of misplacement, incompetent installation and/or undue operation and use of the product in contradiction herewith.

The manufacturer assumes no responsibility for any malfunction, damage or destruction of the product caused by incompetent replacement of parts or due to the use of reproduction parts or components.

The manufacturer shall not be liable and responsible for any loss or damage incurred as a result of a natural disaster or any other unfavorable natural condition.

The manufacturer shall not be held liable for any damage of the product arising during the shipping thereof.

The manufacturer shall not make any warrant with regard to data loss or damage.

The manufacturer shall not be liable and responsible for any direct or indirect damage incurred as a result of a use of the product in contradiction herewith or a failure of the product due to a use in contradiction herewith.

All applicable legal regulations concerning the product installation and use as well as provisions of technical standards on electric installations have to be obeyed. The manufacturer shall not be liable and responsible for damage or destruction of the product or damage incurred by the consumer in case the product is used and handled contrary to the said regulations and provisions.

The consumer shall, at its own expense, procure software protection of the product. The manufacturer shall not be held liable for any damage incurred as a result of the use of deficient security software.

The consumer shall, without delay, change the access password for the product after installation. The manufacturer shall not be held liable or responsible for any damage incurred in connection with the use of the original password.

The manufacturer also assumes no responsibility for additional costs incurred by the consumer as a result of making calls to increased tariff lines.

## Directives, Laws and Regulations

**2N Access Unit M** conforms to the following directives and regulations:

### EU

- 2012/19/EU on waste electrical and electronic equipment




- 2014/53/EU for radio equipment
- 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment

## Industry Canada


This Class B digital apparatus complies with Canadian ICES-003/NMB-003.

## Legislation of Thailand

เครื่องโทรคมนาคมและอุปกรณ์นี้  
มีความสอดคล้องตามมาตรฐานหรือขอ  
กำหนดทางเทคนิคของ กสทช.



เครื่องวิทยุคมนาคมนี้ ได้รับยกเว้น ไม่ต้องได้  
รับใบอนุญาตให้มี ใช้ซึ่งเครื่องวิทยุคมนาคม  
หรือตั้งสถานีวิทยุคมนาคมตามประกาศ กสทช.  
เรื่อง เครื่องวิทยุคมนาคม และสถานีวิทยุ  
คมนาคมที่ได้รับยกเว้นไม่ต้องได้รับใบอนุญาต  
วิทยุคมนาคมตามพระราชบัญญัติวิทยุคมนาคม  
พ.ศ. 2498



**nab.** | โทรคมนาคม  
กำกับดูแลเพื่อประชาชน  
Call Center 1200 (InswS)

## Legislation of Japan

本製品は、特定無線設備の技術基準適合証明を受けています。

この装置は、クラス B 機器です。この装置は、住宅環境で使用この装置は、クラス B 機器です。この装置は、住宅環境で使用するを目的としています。この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。  
VCCI - B

本製品は、シールドネットワークケーブル(STP)を使用して接続してください。また適切に接地してください。

本製品は電気通信事業者（移動通信会社、固定通信会社、インターネットプロバイダ等）の通信回線（公衆無線 LAN を含む）に直接接続することができません。本製品をインターネットに接続する場合は、必ずルータ等を経由し接続してください。

## Electric Waste and Used Battery Pack Handling



Do not place used electric devices and battery packs into municipal waste containers. An undue disposal thereof might impair the environment!

Deliver your expired household electric appliances and battery packs removed from them to dedicated dumpsites or containers or give them back to the dealer or manufacturer for environmental-friendly dispos-

## General Instructions and Cautions

al. The dealer or manufacturer shall take the product back free of charge and without requiring another purchase. Make sure that the devices to be disposed of are complete.

Do not throw battery packs into fire. Battery packs may not be taken into parts or short-circuited either.



2N Access Unit M – Installation Manual

© 2N Telekomunikace a. s., 2025

**2N.com**