

# **R29X Quick Guide**

## **Unpacking**

Before you begin using the device, please check the version you got and ensure that the following items are included



**R29X** 

Speaker

Card Reader

Fingerprint Reader(for R29CT/R29T only)

# Akuvox Smart Intercom

# **R29X Quick Guide**

### Installation Environment

Please do not place device under direct sunlight.

If installing the device indoors, please keep device at least 2 meters away from light, and at least 3 meters away from window and door .



Direct sunlight







Attention:


Biometric recognition product may not be considered 100% to fit in any identification application. For higher security purpose or scenario, please set up access authentication combination.

#### Installation

#### 1. Step 1: Bracket/Box Installation

#### 1.1 Wall Mounting

#### 1.1.1 With embedded one-gang junction box(86x86 mm)in the wall



box with two M4x30 crosshead screws.

Fix the wall-mounting Mark the four holes box on 86 embedded of the wall-mounting M4x30 crosshead box on the wall

Take down two screws and wall-mounting box.

Use a hand drill with 6 mm diameter bit to make holes in the marked positions.


Insert the plastic wall anchors into the holes

Fix the wall-mounting box with four ST4x20 crosshead screws and two M4x30 crosshead screws.

#### 1.1.2 Without embedded one-gang junction box in the wall



Mark the six holes of the wall-mounting box on the wall.



Use a hand drill with 6 mm diameter bit to make the holes in marked

\*Please note the relative position in the left figure and the maximum error should less than 5 mm.



Insert the plastic wall anchors into the holes you drilled before.



Fix the wall-mounting box with six ST4x20 crosshead screws.


# Akuvox Smart Intercom

## R29X Quick Guide

# 1.2 Flush Mounting 1.2.1 Normal installation



Dig out a square hole (height\*width\*depth=314\*124\*53mm) Note: The size of the hole should be a little larger than recommended value that can accommodate all cables.



Insert the flush-mounting box into the hole and make sure the cables of the device can route through the cable hole. Then mark the six holes of the flush-mounting box on the wall.



Take down the flush-mounting box, then use a hand drill with 6mm diameter bit to make holes in the marked positions.



Use six M4x10 crosshead screws to fix the flush-mounting bracket on the flush-mounting hox.



Place the flush-mounting box into the square hole until the edges of which align to the wall and make all cables go through the cable hole. Fix the flush-mounting box with six ST4x20 crosshead screws.



Insert the plastic wall anchors into the hole you drill before.

## 1.2.2 Or you can choose another simple method without fixing ST4x20 crosshead

#### screws



Dig out a square hole (height\*width\*depth=314\*124\*53mm) Note: The size of the hole should be a little bigger than recommended value that can accommodate all cables.



Use cement or non-corrosive structural adhesives to fill the gap between the wall and embedded box. Wait the adhesive material desiccation, go to the next step.

#### Waterproof Tips:

- For flush mounting installation, it is recommended to fill the gaps around the embedded box for waterproofing (to prevent water from entering the back cover of the door phone from the gap).
- For wall mounting installation, it is recommended to lock the wall-mounted bracket and the wall so that the EVA pasted on the bottom of the wall mounting bracket is close to the wall without a gap (to prevent water from entering the back cover of the door phone from the gap)
- Or it is recommended to use rain cover.




Use six M4X10 crosshead screws to fix the flush-mounting bracket on the flush-mounting box.

# Akuvox Smart Intercom


# R29X Quick Guide


#### 1.3 Plasterboard Mounting




Dig through a square hole (height\*width=312\*117.5 mm) Note:This mounting mode is only compatible with wall thickness of 1-25 mm.








Fixing the four crosshead screws to tight the bracket.




Toggle the screw outward to make the claw of the sheet metal insert the back of the wall.



According to your need, attach the metal frame to the bracket.


## 2. Step 2: Wiring cover Installation



For convenient wiring, hang R29X on the wall-mounting box/flush-mounting bracket with rope. Then insert the sealing ring into the groove.




Make cables go through the wiring cover, connecting to the corresponding interfaces of the main board. Choose a suitable size rubber plug to compress cables, then fasten the sealing pressing plate with two STI.7x4 crosshead screws.



Use four M3x5 crosshead screws to fix the wiring cover.



#### 3. Step 3: Device Mounting




1.Place the device into the wall-mounting box / flush-mounting bracket until the edges of which align to the wall. Then pull the device downward and ensure the groove of it hooks to the lock catches of the back box.

2.Use the Allen wrench to tighten the device with two M3x6 crosshead screws.



Installation completed.

## **Application Network Topology**



## Wire Length & AWG Table


Please follow the properly measured wire gauge/length to install device:

	20 AWG	22 AWG	24 AWG	26 AWG
12V 1.5A Adapter	≤20m	≤15m	\	١



# R29X Quick Guide

## **Device Wiring**



## **Configuration**

1.IP Address Checking: Press 9999 in dialing interface, then input 3888 to enter the system interface. Click Info to check the IP address. R29X uses DHCP by default.

2.Account Registration:On web UI, go to the path: Account > Basic page to register account and fill in the account information. ( Please refer to admin guide for more information)

3.DTMF Code Configuration:On web UI, go to the path: Intercom > Relay > Relay ID/ DTMF choose the DTMF code number in corresponding area.

### **Operation**

#### Make a call:

Input the room number, press Dial key to make a call.

#### Receive a call:

R29X supports Auto Answer by default. Incoming calls will be answered automatically.

#### Unlock by DTMF:

During the call, press the corresponding DTMF code from answer unit to unlock R29X remotely.

#### Unlock by Private Key:

In the PIN/PASSWORD interface, enter the password to open the door.

#### Unlock by RF Card:

Place the predefined RF Card in the card reader area to open the door.

#### Notice Information

Information contained in this document is believed to be accurate and reliable at the time of printing. This document is subject to change without notice, any update to this document can be viewed on Akuvox's website: <a href="http://www.akuvox.com">http://www.akuvox.com</a> © Copyright 2022 Akuvox Ltd. All rights reserved.

#### AKUVOX (XIAMEN) NETWORKS CO., LTD.

Add.: 10/F, NO.56 GUANRI ROAD, SOFTWARE PARK II, XIAMEN 361009, CHINA www.akuvox.com

