

PrimeWiFi

WI-FI INTERFACE FOR PRIME CONTROL PANELS



The optional PrimeWiFi module provides Prime series control panels with Wi-Fi connectivity.

It inserts directly into the main board of the Prime control panel and provides it with a wireless connection to the home or business Wi-Fi network. Connectivity to the network will allow the installer to remotely program and supervise the system via the Prime/STUDIO software and the connection to the INIM Cloud.

Main features

Plug-in mounting to motherboard

Encryption of AES-128 bit data

LTE-ANT 100B GSM/LTE antenna with magnetic base and 2 mt. cable

Control panel programming and management over IP with Prime/STUDIO software

Static IP address management

Dynamic DNS management

Management of up to 10 simultaneous connections

Inim Cloud Connectivity

Digital communicator with SIA-IP protocol for alarm receiving centres

Sending of emails with attachments and SSL support

UPNP

Web server for PC, tablet and smartphone connections with the following functions:

- Virtual keypad

- Scenario management

- Zone management

- Partition management

- Interactive and customizable graphic maps

- ONVIF webcam

 - Live webcam management

 - Sending of email/archive webcam events

- Timer visualization

- Events log visualization

ORDER CODES

PrimeWiFi: Wi-Fi interface for Prime control panels for Internet connections with TCP-IP protocol.

LTE-ANT100B: GSM/LTE antenna with magnetic base and 2 meter cable.

PRIMEWIFI

CE

EN 50131-1
EN 50131-3
EN 50136-1
EN 50136-2
EN 50131-5-3
EN 50130-4
EN 50130-5
CEB T031



Centobuchi, via Dei Lavoratori 10
63076, Montepandone (AP), ITALY
Tel. +39 0735 705007 _ Fax +39 0735 704912

info@inim.biz _ www.inim.biz

Inim distributor's stamp and signature