





Safety Technology International



European Office
Taylor House • 34 Sherwood Road • Bromsgrove
Worcestershire • B60 3DR • England
Tel: 44 (0) 1527 520 999 Fax: 44 (0) 1527 501 999
E-mail: info@sti-emea.com • Web: www.sti-emea.com

USA - Headquarters
2306 Airport Road • Waterford, Michigan 48327-1209
Phone: 248-673-9898 • Fax: 248-673-1246
Toll Free: 800-888-4784 • E-mail: info@sti-usa.com
Web: www.sti-usa.com

External Dimensions



SECTION B-B



Internal Dimensions

SECTION A-A

INSTALLATION INSTRUCTIONS

1. Center and place wire guard over device or product to be protected and mark all 4 hole locations with pencil or marker.
2. Drill all 4 holes using 1/4" diameter drill 1-1/2" deep.
3. Insert anchors into drilled holes.
4. Place wire guard in position, insert screws and tighten.

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details. Electronic warranty form at www.sti-usa.com/wc14.

INSTALLATION OF STI-9729 WIRE GUARD DAMAGE STOPPER®

All specifications and information shown were current as of publication and are subject to change without notice.

9729 MAY2017